



Herrscher



拉手&指示鎖

Handle&Lock instructions





41603

SS	01
CH	02
SB	03
PB	04




41604

SS	01
CH	02
SB	03
PB	04




41600


SS	01
CH	02
SB	03
PB	04




41606




SS	01
CH	02
SB	03
PB	04




41605





SS	01
CH	02
SB	03
PB	04




41602





SS	01
CH	02
SB	03
PB	04




41203





41204





41205




41200




41201




41202






40610


width	length
7/8"	2",3",4",5",6",8"
1"	2",3",4",5",6",8"



Brass door bolt/插銷(鋼)




40603




Stain steel door bolt/插銷(不銹鋼)




40601



Stain steel door bolt/插銷(不銹鋼)



40602



Stain steel door bolt/插銷(不銹鋼)